



Action tips  
for gas safety

Gas inspection  
video guide



# Tips for Inspecting Your Gas Facilities

## 1 Check the gas range connection and fuse cock

Apply soapy water to the gas range connection and check for bubbles for 10 seconds.  
In case of a gas leak, ventilate the area first and then contact your gas supplier.



## 2 Check the condition of external piping and hoses

Check the gas connection and hose condition.  
If you notice any signs of aging or cracking, contact your gas supplier.



## 3 Safety inspection of gas boilers

Check whether the boiler's ventilation hood is out of place or if the ventilation pipe is dented.

\* When inspecting the boiler, always make sure the power is off.



## 4 Block gas facilities before moving

For safety, ask your gas supplier to block the gas facility before moving.



## 5 Keep butane cans safe

Keep flames away from the butane can and make sure the area is well ventilated during use.

Do not use grills that are larger than the portable burner stand.



※ If you find any unsafe conditions during self-inspection, please contact your local gas supplier or Korea Gas Safety Corporation(1544-4500).



KOREA GAS SAFETY CORPORATION